








L SERIES

High Performance AIR Cooler

L50 360BK/L50 360WH/L50 240BK/L50 240WH

USER GUIDE


01 Buckle and accessories




INTEL: **A** **C** **D** **E**


AMD: **C** **D** **F**

02 360Fan water drain installation




03 240Fan water drain installation









A




LGA1851/1700




LGA115X/1200






1




2









1




2





13 Connection for L50



Installation Demonstration



