



U SERIES

High Performance AIR Cooler
U60


USER GUIDE

Please scan the QR code to watch the installation tutorial video.



01 Buckle and accessories


A



B




C




D



E




F




INTEL: **A** **C** **D** **F**


AMD: **C** **D** **E** **F**






A





LGA1851/1700





LGA115X/1200








































4-PIN/CPU_
FAN/CPU_OPT

